







# Cylinder Trolley

TOPARC




ITEM NO.	DESCRIPTION	QTY.
A	BOLT M8 x 35	2
B	WASHER M8	4
C	NYLOCK NUT M8	2
D	BOLT M6 x 35	2
E	BOLT M6 x 12	6
F	WAHSER M6	16
G	NYLOCK NUT M6	8
H	FLAT WASHER 1"	 4
I	SPRING WAHSER 1"	 2
J	WHEEL SPACER	 2
K	LYNCH PIN	 2
L	WRENCH	 2

ITEM NO.	DESCRIPTION	QTY.
1	DIVIDER	1
2	MAIN PIPE	1
3	T-HANDLE PIPE	1
4	SIDE SUPPORT BARS	2
5	WHEEL	2
6	CYLINDER SUPPORT BRACKET	1
7	BASE	1





1. Divider    2. Main Pipe    3. T-Handle Pipe

4. Side Support Bars



5. Wheel


6. Cylinder Support Bracket



7. Base


## STEP - 1

Attach Main Pipe to Base using Bolt (A), Washer (B) & Nut (C).




## STEP - 2

Attach Divider to Base & to the Main Pipe using Bolt (E), Washer (F) & Nut (G).




## STEP - 3

Insert T-Handle Pipe into Main Pipe. Then fit the Cylinder Support Bracket and tighten it with Bolt (D), Washer (F) & Nut (G).




## STEP - 4

Affix Side Support Bars to Base & to the Cylinder Support Bracket as shown in the diagram below, using Bolt (E), Washer (F) & Nut (G).



## STEP - 5

Insert a Wheel Spacer (J) then a Flat Washer (H) on one side of the Axle. Insert the Wheel then a Spring Washer (I) and then again a Flat Washer (H). Lastly insert Lynch Pin (K) and lock the Lynch Pin by snapping its ring downwards. Repeat these steps for the other wheel too.



*Your Cylinder Trolley is ready to use.*